



System overview

- Hardware
- NTi Audio FX100 2-chn Audio analyzer
 - Low-induction load resistors

- Control software
- FX-Control

- Measurements
- Step 1 (GlideSweep)*
- Frequency response
 - Phase
 - Total Harmonic Distortion (THD)
 - Gain
 - Output power
- Step 2 (StepSweep)*
- Crosstalk left / right
 - Linearity (amplitude sweep)
 - Maximum output level @ <1 % THD
- Step 3 (FFT)*
- Noise
 - Hum

All information is subject to change without notice. FX100 and FX-Control are Trademarks of NTi Audio AG.

NTi Audio AG
Im alten Riet 102
9494 Schaan
Liechtenstein, Europe
Phone +423 239 60 60
Fax +423 239 60 89
info@nti-audio.com

NTi Americas Inc.
PO Box 231027
Tigard, Oregon 97281
USA
Phone +1 503 684 7050
Fax +1 503 684 7051
americas@nti-audio.com

NTi China Ltd.
Room 722, 7F, Building 6-3A,
No 1388, Bin He Rd.
215000 Suzhou, China
Phone +86 512 6802 0075
Fax +86 512 6802 0097
china@nti-audio.com

NTi Japan Ltd.
Ryogokusakamoto Bldg. 1-8-4
Ryogoku, 130-0026 Sumida-ku
Tokyo, Japan
Phone +81 3 3634 6110
Fax +81 3 3634 6160
japan@nti-audio.com