

## HOW TO CLEAN TEACHLOGIC MICROPHONES

Periodic cleaning of the microphone is recommended to avoid the buildup of common contaminants like dust, lint, dirt, and oil, while disinfecting the microphone protects the health and safety of users.

**\*\*\*NEVER SPRAY WITH LIQUID, SUBMERGE, OR USE ABRASIVE CLEANERS\*\*\***


### Do

1. First remove dust & lint build up with a light spray of canned compressed air or dust cloth.
2. Use a disinfectant wipe to wipe the area first. Use extra care around the sensitive areas.
  - If you encounter a very damp wipe, squeeze to remove the excess liquid before use.
3. Dry with a soft, lint-free cloth.

### Don't

- Do not use disinfectant wipes containing bleach.
- Do not allow the liquid from the disinfectant wipe to sit or pool on the area being disinfected.
- Do not use rough towels or cloths to dry the microphone.
- Do not use excess force when disinfecting the sensitive areas of the microphone.
- Do not heavily spray compressed air into any part of the microphone.

**Sapphire Microphone Sensitive areas**



**Handheld Microphone Sensitive Areas**

