

AMHEAVYG

Heavy-Duty Gooseneck Microphone

Thank you for purchasing this quality Australian Monitor product.

The AMHEAVYG is a heavy-duty gooseneck microphone design specifically for continuous high usage in commercial environments. The heavy-duty goose neck and dynamic capsule provide dependable reliability which ensures years of reliable operation. Featuring a momentary switch the AMHEAVYG is also capable of providing dry contact closure to trigger pre-announce tone generators.

The AMHEAVYG is the ideal solution for PA paging scenarios such as supermarkets, service stations, fast food outlets and many other demanding commercial environments.

What's in the box?

1 x AMHEAVYG Gooseneck Microphone

The instruction manual you are now reading


Features

Tailored for PA paging announcements

Momentary including dry contact switch

Heavy Duty Gooseneck

Heavy duty dynamic capsule





INSTALLING YOUR AMHEAVYG MICROPHONE

Installing your Microphone

- 1 Choose a suitable flat surface to install the microphone.
- 2 Using a drill or spade bit drill a 5 mm hole in the surface to run the cable through.
- 3 Using a marker or punch and mark the position of the 3 holes in the microphone base.
- 4 Using suitable fasteners secure the microphone in place.

Wiring your microphone

The AMHEAVYG is shipped with an unterminated 5 wire cable. This allows the installer to customise the connection type between the AMHEAVYG and device input.

The AM HEAVY provides a balanced microphone output signal. It also provides a normally open (N/O) dry contact closure output from the momentary switch allowing connection to third party devices such as a pre-announce tone generator.

Please follow the table below for successful wiring and operation of your microphone.


Audio Wiring Termination

Red wire	Audio Positive (+)
Black wire	Audio Negative (-)
Drain / Shield	Audio Ground


Switch Wiring Termination

Green wire	Switch
White wire	Switch

(Normally Open (N/O))




DIMENSIONS



250 Hz ----- 2000 Hz -----
 500 Hz 4000 Hz -----
 1000 Hz ——— 8000 Hz -----

TYPICAL POLAR PATTERNS




TYPICAL FREQUENCY RESPONSE

Specifications

Transducer Type	Dynamic
Polar Pattern	Supercardioid
Frequency Response	100Hz–15Khz
Sensitivity	1.3 mV/Pa -58 dBV
Electrical Impedance	500 Ω
Min. Load Impedance	2000 Ω
Max. SPL	135dB @ 1% THD
Finish	Silver
Cable	Unterminated 4.0 mm shielded 1.5m 5 core
Audio Connection	Red = Audio + Black = Audio – Drain = Audio Ground
Switch Connection (Normally Open N/O)	Green = Switch White = Switch
Dimensions	586mm x 71mm
Net Weight	750g

IMPORTANT SAFETY INFORMATION

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12.  Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. This appliance shall not be exposed to dripping or splashing water and that no object filled with liquid such as vases shall be placed on the apparatus.
16. Plug this apparatus to the proper wall outlet and make the plug to be disconnected readily operable.
17. Mains plug is used as disconnected device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
18. Warning: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
19. An appliance with a protective earth terminal should be connected to a mains outlet with a protective earth connection.
20. The apparatus should be disconnected from the mains completely before speaker wiring. The speaker output should be properly protected from direct contact and pay attention to speaker connections, terminals and speaker wiring during normal operation.

WARNING!

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT USE THE PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE. TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION

THESE SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED SERVICE PERSONNEL ONLY. TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**

WARNING:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



For European Union countries: This symbol on the product or its packaging indicates that this product must not be disposed of with other waste.

Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.

Please contact your local authority for further details of your nearest designated collection point.

Rating plate and caution marking are marked on the back enclosure of the apparatus



ENGINEERED BY AUSTRALIAN MONITOR
Address: 1 Clyde St, Silverwater NSW 2128 Australia.
Website: www.australianmonitor.com.au
International enquiries email: international@australianmonitor.com.au
ABN 35 007 573 417